SLS320 LINEAR DISPLACEMENT SENSOR

The SLS320 range is designed to provide maximum performance benefits within a body diameter of 32mm, with stroke lengths from 250 to 1600mm. With a choice of mounting options and accessories, this sensor is ideally suited to a wide range of heavier duty industrial applications, for medium to long stroke linear position sensing.

PERFORMANCE

PERFORIVIANCE															
Electrical stroke E	mm	250	300	350	400	450	500	550	600	650	700	750	800	850	900
Resistance ±10%	kΩ	10	12	14	16	18	20	22	24	26	28	30	32	34	36
Power dissipation at 20°C	W	5.0	6.0	7.0	8.0	9.0	10	11	12	13	14	15	16	17	18
Electrical stroke E	mm	950	1000	1050			1200			1350		1450			
Resistance ±10%	kΩ	38	40	42	44	46	48	50	52	54	56	58	60	62	64
Power dissipation at 20°C	W	19	20	21	22	23	24	25	26	27	28	29	30	31	32
Independent linearity															
guaranteed	±%	0.15													
typical	±%	0.05													
Applied voltage - maximur	n Vdc	74													
Electrical output		Minin	num of	0.5% to	99.5%	5 applie	ed volts								
Resolution		Virtua	ılly infin	ite											
Hysteresis (repeatability)	mm	Less t	han 0.0)1											
Operational temperature	°C	-30 t	o +100												
Output smoothness		To MI	L-R-390)23 gra	de C 0	.1%									
Insulation resistance		Great	ter than	100M G	2 at 50	OVdc									
Operating mode		Volta	ge divid	er only	- see C	Circuit R	lecomm	nendatio	on belo	W					
Wiper circuit impedance		Minin	num of	100 x	track re	esistanc	e or 0.	5M Ω (v	hichev	er is gr	eater)				
Operating force - maximur	n														
sealed	gf	2000	in horiz	zontal p	lane (b	oreak-o	ut force	e 5000g	gf)						
unsealed	gf	1500	in horiz	zontal p	lane (b	oreak-o	ut force	e 2000g	gf)						
Life at 250mm per second		Туріса	ally in e	cess of	100 m	nillion c	operatio	ons (50	x 10⁰ c	ycles) a	at 25mr	n strok	e lengtł	۱	
Dither life		200 r	nillion d	operatio	ns (100	0 x 10⁰	cycles)	at ±0.	5mm, o	60Hz					
Sealing		IP50 :	standar	d - IP66	see op	otions									
Shaft seal life		20 m	illion op	peration	s (10 x	10⁰ cy	cles) - r	replace	able						
Shaft velocity - maximum	m/s	10													
CIRCUIT		Hybrid	d track j	ootentio	meters	feature	e a high	wiper	contact	resistar	nce, the	refore	operatio	onal che	ecks
RECOMMENDATION	J	should	d be car	ried ou	t only ii	n the vo	oltage d	livider r	node. H	Hybrid t	rack po	tention	neters sl	hould b	е
		used	only as	voltage	divider	s, with	a minin	num wi	per circ	uit imp	edance	of 100	x track	resista	nce
		or 0.5	$5 M\Omega$ (wh	nichever	is grea	ater). C	peratio	n with v	viper ci	rcuits o	f lower	impeda	ance wi	ll degra	de
		the ou	utput sm	oothne	ss and	affect tl	ne linea	arity.							
OPTIONS															
Compact shaft		Comp	oact sha	ft will re	educe d	dimensi	on D b	y 50mr	n						
Integral shaft seal - IP 66		Desig	ned to a	accept i	ntegral	shaft s	eal to g	give IP6	6 ratin	g					
Cabled socket		1m oi	r 10m c	abled s	ocket a	issemb	lies ava	ilable							
Mounting		Body	clamp o	or flang	e mour	nting ki	ts can b	be supp	lied						
Protective sleeve		For al	l stroke	lengths	s - self a	aligning	g bearii	ngs onl	y. See d	ordering	g code				

Mounting kits _

ACCESSORIES

Flange kit - SA59660
Protective sleeve - SA202988/...../....

Body clamp kit - SA59661

Shaft L = long, C = compact
 Electrical stroke (select to match SLS320 sensor)
 Not available as a spare part for 1150 to 1600mm strokes

AVAILABILITY

14

All standard configurations can be supplied rapidly from the factory - check with your local supplier for more details

ORDERING CODES



Electrical stroke ______ Shaft L = long, C = compact____ Protective sleeve N=None, P=Fitted

- Cabled socket 00=None 01=1m 10=10m - Sealing 50 = IP50, 66 = IP66

DIMENSIONS AND MOUNTING OPTIONS

Note: drawings not to scale

Mounting recommendations

For units 1150 to 1600mm stroke, we recommend the use of body clamp or flange mounting kits to support the sensor when horizontally mounted. Alternatively, use the protective sleeve kit with the self aligning bearing mountings to provide increased rigidity.


Electrical stroke E	mm
Mechanical stroke M	mm
Body length B	mm
Between centres D	
standard sensor (L)	mm
compact shaft sensor (C)	mm
Sleeve length F	
standard sensor (L)	mm
compact shaft sensor (C)	mm
Weight approximate (no slee	eve)
standard sensor (L)	g
compact shaft sensor (C)	g
Electrical stroke E	mm
Electrical stroke E Mechanical stroke M	mm mm
Mechanical stroke M	mm
Mechanical stroke M Body length B	mm
Mechanical stroke M Body length B Between centres D	mm mm
Mechanical stroke M Body length B Between centres D standard sensor (L)	mm mm
Mechanical stroke M Body length B Between centres D standard sensor (L) compact shaft sensor (C)	mm mm
Mechanical stroke M Body length B Between centres D standard sensor (L) compact shaft sensor (C) Sleeve length F	mm mm mm mm
Mechanical stroke M Body length B Between centres D standard sensor (L) compact shaft sensor (C) Sleeve length F standard sensor (L)	mm mm mm mm mm
Mechanical stroke M Body length B Between centres D standard sensor (L) compact shaft sensor (C) Sleeve length F standard sensor (L) compact shaft sensor (C)	mm mm mm mm mm
Mechanical stroke M Body length B Between centres D standard sensor (L) compact shaft sensor (C) Sleeve length F standard sensor (L) compact shaft sensor (C) Weight approximate (no slee	mm mm mm mm mm mm eve)

ELECTRICAL CONNECTIONS


Right angled, cabled socket


E series M12 to IEC 60947-5-2 PUR jacket. Conforms to DIN/VDE 0660 part 208A2

SELF ALIGNING BEARING MOUNTING




PROTECTIVE SLEEVE OPTION - P





MOUNTING

250 255 366	300 305 416	350 355 466	400 405 516	450 455 601	500 505 651	550 555 701	600 605 751	650 655 801	700 705 851	750 755 901	800 805 986	850 855 1036	900 905 1086
480 430	530 480	580 530	630 580	710 660	760 710	810 760	860 810	910 860	960 910	1010 960	1095 1045	1145 1095	1195 1145
372 322	422 372	472 422	522 472	607 557	657 607	707 657	757 707	807 757	857 807	907 857	992 942	1042 992	1092 1042
590 555	673 638	756 721	839 804	922 887	1005 970	1088 1053	1171 1136	1254 1219					1669 1634
950	1000	1050	1100	1150	1200	1250	1300	1350	1400	1450	1500	1550	1600
950 955	1005	1055	1105	1155	1205	1255	1305	1355	1405	1455			1600 1605
	1005		1105	1155	1205	1255	1305	1355	1405	1455	1505	1555	
955	1005	1055 1236	1105	1155 1371	1205	1255 1471	1305 1521	1355 1571	1405 1621	1455 1671	1505 1721	1555 1771	1605
955 1136 1245	1005 1186 1295	1055 1236	1105 1286 1395	1155 1371	1205 1421 1530	1255 1471 1580	1305 1521 1630	1355 1571	1405 1621 1730	1455 1671 1780	1505 1721 1830	1555 1771 1880	1605 1821
955 1136 1245 1195	1005 1186 1295	1055 1236 1345 1295	1105 1286 1395 1345	1155 1371 1480 1430	1205 1421 1530 1480	1255 1471 1580 1530	1305 1521 1630 1580	1355 1571 1680 1630	1405 1621 1730 1680	1455 1671 1780	1505 1721 1830 1780	1555 1771 1880 1830	1605 1821 1930
955 1136 1245 1195 1142	1005 1186 1295 1245	1055 1236 1345 1295 1242	1105 1286 1395 1345 1292	1155 1371 1480 1430 1377	1205 1421 1530 1480 1427	1255 1471 1580 1530 1477	1305 1521 1630 1580 1527	1355 1571 1680 1630	1405 1621 1730 1680 1627	1455 1671 1780 1730 1677	1505 1721 1830 1780	1555 1771 1880 1830	1605 1821 1930 1880
955 1136 1245 1195 1142 1092	1005 1186 1295 1245 1192	1055 1236 1345 1295 1242	1105 1286 1395 1345 1292 1242	1155 1371 1480 1430 1377 1327	1205 1421 1530 1480 1427	1255 1471 1580 1530 1477 1427	1305 1521 1630 1580 1527 1477	1355 1571 1680 1630 1577 1527	1405 1621 1730 1680 1627	1455 1671 1780 1730 1677 1627	1505 1721 1830 1780 1727 1677	1555 1771 1880 1830 1777 1727	1605 1821 1930 1880 1827



Cabled Socket

1 metre long No. x61-169-001 10 metres long No. x61-169-010

SPECIALISED DESIGNS

We have considerable experience in solving specific application problems by developing our standard designs to suit individual requirements. Custom-designed solutions are also provided where standard equipment does not fully meet our customer's needs.

SLS320 for heavy duty-cycle dynamic applications

A number of specialist applications have demanded an enhanced operating life beyond that capable from the standard SLS320 sealed linear sensor. To meet this requirement, we have developed a special version of the SLS320, which provides optimum lubrication for the track and sliding mechanism for increased operating life.

Typically the sensors are mounted parallel to actuators fitted to hydraulic motion bases operating leisure ride cabins at amusement parks around the world. Typically the motion bases run a three minute cycle time for up to 12 hours per day. This sensor is ideally suited to similar applications subject to heavy duty dynamic movements.

SPECIFICATION SUMMARY

Refer to page 14 and 15 for full performance specification and dimensions

Electrical stroke E mm	150 to 1600mm only
Sealing	IP66 or IP50
Shaft seal life	20 million operations (10 x 10°) - replaceable
Shaft velocity - maximum m/s	10
OPTIONS	

Compact shaft Cabled socket Mounting **Protective sleeve**

ACCESSORIES

Compact shaft will reduce dimension D (page 15) by 50mm 1m or 10m cabled socket assemblies available Self aligning rod ends standard. Body clamp and flange kits available For 250 to 1600mm stroke lengths - self aligning bearings only.

Mounting kits	Body clamp kit - SA59661
Would in the second	Flange kit - SA59660

Protective sleeve - SA202988/..../....


 Shaft L = long, C = compact Electrical stroke (select to match SLS320 sensor) Not available as a spare part for 1150 to 1600mm strokes

Clamp sleeve (to allow SLS320 to replace Penny+Giles HLP350 in existing installations) - P200863 (2 per sensor)

AVAILABILITY

ORDERING CODES

All standard configurations can be supplied rapidly from the factory - check with your local supplier for more details





www.pennyandgiles.com

Penny & Giles Position sensors, joysticks and solenoids for commercial and industrial applications.

15 Airfield Road Christchurch Dorset BH23 3TG United Kingdom + 44 (0) 1202 409409 + 44 (0) 1202 409475 Fax sales@pennyandgiles.com

665 North Baldwin Park Boulevard City of Industry, CA 91746 USA +1 626 480 2150 +1 626 369 6318 Fax us.sales@pennyandgiles.com

Straussenlettenstr. 7b 85053 Ingolstadt, Germany +49 (0) 841 885567-0 +49 (0) 841 885567-67 Fax info@penny-giles.de

3-1-A, Xiandai Square, No 333 Xingpu Rd, Suzhou Industrial Park, 215126 China +86 512 6287 3380 +86 512 6287 3390 Fax sales@pennyandgiles.com.cn

The information contained in this brochure on product applications should be used by customers for guidance only. Penny+Giles Controls Ltd makes no warranty or representation in respect of product fitness or suitability for any particular design application, environment, or otherwise, except as may subsequently be agreed in a contract for the sale and purchase of products. Customer's should therefore satisfy themselves of the actual performance requirements and subsequently the products suitability for any particular design application and the environment in which the product is to be used.

Continual research and development may require change to products and specification without prior notification. All trademarks acknowledged.

© Penny+Giles Controls Ltd 2012

Innovation In Motion

36 Nine Mile Point Industrial Estate Cwmfelinfach Gwent NP11 7HZ United Kingdom + 44 (0) 1495 202000 + 44 (0) 1495 202006 Fax sales@pennyandgiles.com

